



CDCI can used driveway at 2217

Storage of existing site wall, column and pilaster from 2211 on palette.

Use 4 spaces

Dumpspter Location

Limits of Construction

Pilaster and Column to be savage and stored at 2217

Site Wall to be savage and stored at 2217

